

Plan of the hall


Box on the right (from the spectator's view) - for theatre needs

Boxes on the left - for the promoter's needs

Sound desk - rows 14 and 15 - seats 10 - 14, or directed Light desk - row 31 - unsold row, or directed

Seats for wheelchair users - rows 20 and 21 - max 3 on each side

Ground floor of the hall



Balcony

